

Ground problem



Aluminium stand



Steel Stand

1. Connect one screw on the bottom plate of the cutters to one screw on the stand. (A point in the picture)
2. When you do the 1st step, the problem will be resolved. If it is still existed, please connect one screw on the legs to the "ground", such as the water pipe and etc.(B point in the picture)